

# Class 1 Trip Inspection Minor/Major Defect tear out sheet

## Minor and Major Defects

You may use this list of minor and major defects during your trip inspection test to assist you in your inspection and with stating defects. You must still perform all required inspections of randomly selected items. Do not add to or write on this form. If altered it cannot be used on the test. The Professional Driver's Manual has specific inspection information that outlines what components need to be inspected, the inspection method for each, and what constitutes a minor or major defect.

Systems and components	Minor Defects	Major Defects
<b>Cab</b>	<ul style="list-style-type: none"> <li>□ Driver's or passenger's door does not open.</li> </ul>	<ul style="list-style-type: none"> <li>□ Any door does not close securely.</li> </ul>
<b>Cargo securement</b>	<ul style="list-style-type: none"> <li>□ Cargo is covered but the cover is not attached, or does not cover the cargo, in a manner that complies with the Cargo Securement Regulation.</li> </ul>	<ul style="list-style-type: none"> <li>□ Cargo is not covered or is not secure.</li> <li>□ Cargo securement device is missing, does not work properly or its condition does not comply with the Cargo Securement Regulation.</li> <li>□ Cargo cover's condition does not comply with the Cargo Securement Regulation.</li> </ul>
<b>Dangerous goods</b>		<ul style="list-style-type: none"> <li>□ Dangerous goods handling and transportation requirements under The Dangerous Goods Handling and Transportation Act are not met.</li> </ul>
<b>Driver's controls</b>	<ul style="list-style-type: none"> <li>□ Accelerator pedal, clutch, a gauge, an audible or visual indicator, or an instrument does not work properly.</li> </ul>	
<b>Driver's seat</b>	<ul style="list-style-type: none"> <li>□ Seat is damaged or does not remain in set position.</li> </ul>	<ul style="list-style-type: none"> <li>□ Seatbelt or tether belt is not secure, is missing or does not work properly.</li> </ul>
<b>Emergency equipment and safety devices</b>	<ul style="list-style-type: none"> <li>□ Emergency equipment is missing, damaged or defective.</li> </ul>	
<b>Exhaust system</b>	<ul style="list-style-type: none"> <li>□ Exhaust leak that does not cause exhaust gas to enter the occupant compartment.</li> </ul>	<ul style="list-style-type: none"> <li>□ Exhaust leak that causes exhaust gas to enter the occupant compartment.</li> </ul>
<b>Frame and cargo body</b>	<ul style="list-style-type: none"> <li>□ Damaged frame or cargo body (except as described as a major defect).</li> </ul>	<ul style="list-style-type: none"> <li>□ Visibly shifted, cracked, collapsing or sagging frame member.</li> </ul>
<b>Fuel system</b>	<ul style="list-style-type: none"> <li>□ Missing fuel tank cap.</li> </ul>	<ul style="list-style-type: none"> <li>□ Fuel tank is not secure.</li> <li>□ Dripping fuel leak.</li> </ul>
<b>Glass and mirrors</b>	<ul style="list-style-type: none"> <li>□ Windows or mirrors do not allow the driver to see to the side and rear of the vehicle on both sides as a result of being damaged, missing or not adjusted properly.</li> <li>□ Window glass or mirror has broken or damaged attachments onto vehicle body.</li> <li>□ Driver's view of the road is obstructed in the area swept by the windshield wipers.</li> </ul>	<ul style="list-style-type: none"> <li>□ Missing windshield.</li> </ul>
<b>Heater / defroster</b>	<ul style="list-style-type: none"> <li>□ System or a control does not work properly.</li> </ul>	<ul style="list-style-type: none"> <li>□ Defroster does not provide an unobstructed view through the windshield.</li> </ul>
<b>Horn</b>	<ul style="list-style-type: none"> <li>□ Horn does not work properly.</li> </ul>	

Systems and components	Minor Defects	Major Defects
<b>Lamps and reflectors</b>	<ul style="list-style-type: none"> <li>❑ Lamp does not work properly.</li> <li>❑ Reflector is partly or completely missing.</li> </ul>	<ul style="list-style-type: none"> <li>❑ Failure of both low-beam headlamps when lamps are required to be lit.</li> <li>❑ Failure of both rearmost tail lamps when lamps are required to be lit.</li> <li>❑ Failure of one rearmost turn indicator lamp at any time.</li> <li>❑ Failure of both rearmost brake lamps at any time.</li> </ul>
<b>Steering</b>	<ul style="list-style-type: none"> <li>❑ Steering wheel lash is greater than normal.</li> </ul>	<ul style="list-style-type: none"> <li>❑ Steering wheel is not secure.</li> <li>❑ Steering wheel movement indicates binding or looseness.</li> <li>❑ Steering wheel lash exceeds the limit that constitutes a hazardous condition.</li> </ul>
<b>Suspension system</b>	<ul style="list-style-type: none"> <li>❑ Air leak in air suspension system.</li> <li>❑ Broken spring leaf.</li> <li>❑ Suspension fastener is loose, missing or broken.</li> </ul>	<ul style="list-style-type: none"> <li>❑ Damaged air bag (patched, cut, bruised, cracked to braid).</li> <li>❑ Deflated air bag.</li> <li>❑ Air bag mounted insecurely.</li> <li>❑ Cracked or broken main spring leaf, or more than one broken spring leaf.</li> <li>❑ Part of spring leaf or suspension is missing, shifted out of place or in contact with another vehicle component.</li> <li>❑ Loose U-bolt.</li> </ul>
<b>Tires</b>	<ul style="list-style-type: none"> <li>❑ Damaged tire tread or sidewall.</li> <li>❑ Tire leaking (if leak can be felt or heard, tire is to be treated as flat).</li> </ul>	<ul style="list-style-type: none"> <li>❑ Flat tire.</li> <li>❑ Tire tread depth is less than the wear limit that constitutes a hazardous condition.</li> <li>❑ Tire is marked "not for highway use".</li> <li>❑ Tire has exposed cords in the tread or outer sidewall area.</li> <li>❑ Tire is in contact with another tire or any vehicle component other than mudflap.</li> </ul>
<b>Vehicle in general</b>		<ul style="list-style-type: none"> <li>❑ Serious damage or deterioration that is noticeable and may affect the vehicle's safe operation.</li> </ul>
<b>Wheels, hubs and fasteners</b>	<ul style="list-style-type: none"> <li>❑ Hub oil below minimum level if fitted with sight glass.</li> <li>❑ Leaking wheel seal.</li> </ul>	<ul style="list-style-type: none"> <li>❑ Wheel has loose, missing, damaged or ineffective fastener.</li> <li>❑ Damaged wheel or wheel component.</li> <li>❑ Evidence that wheel, hub or bearing will fail soon.</li> </ul>
<b>Windshield wiper / washer</b>	<ul style="list-style-type: none"> <li>❑ System or a control does not work properly.</li> <li>❑ Wiper blade is damaged or missing.</li> <li>❑ Wiper or washer does not work properly.</li> </ul>	<ul style="list-style-type: none"> <li>❑ Wiper or washer fails to adequately clear driver's field of vision in area swept by driver's side wiper when prevailing weather conditions require use of wiper or washer.</li> </ul>